

How to switch your controller from Fahrenheit to Celsius

NOTE: Grainfathers sold in the USA and Canada should come with a control box that displays in Fahrenheit. It may seem as though the temperature is reading in celsius as the third digit is in the subscript e.g 16 $_{.7}$. This is actually reading 167°F not 16.7°C. When it is set to Celsius the subscript digit is a point of a degree e.g 21. $_{.1}$ is 21.1°C.

- 1. Press the Up and DOWN arrows together and hold for a few seconds until the screen displays "FO1".
- 2. Press and release the SET key to enter Password.
- 3. Change the value so that it displays "231" by using the UP and DOWN arrows.
- 4. Press and the release the SET key.
- 5. Press the UP arrow until it displays "uni"
- 6. Press the SET key, it will display the item of either 'C' Celsius or 'F' Fahrenheit, press the UP or DOWN arrow to select either Celsius or Fahrenheit.
- 7. Press the SET key, it will display "FAC", then it will display "F01".
- 8. Press UP arrow until you select the "FO4".
- 9. Press and release SET key.
- 10. Press the UP or DOWN arrow to select "105".
- 11. Press the SET key.
- 12. Press UP arrow until you select the "F05".
- 13. Press and release the SET key.
- 14. Press the DOWN arrow to select ".5".
- 15. Press the SET key.
- 16. Press UP arrow until you select the "FO8".
- 17. Press and release the SET key.
- 18. Press the DOWN arrove to reduce the number all of the way down until it reads "HOT".
- 19. Press the SET key.
- 20. The controller will time out and return to normal operation.

Function	Description	Value 'F'	Value 'C'
F01	Password	231	231
F04	Max. Set Value	221	105
F05	Hysterosis	2	.5
F08	Heating/Cooling	HOT	НОТ